

Celadon Inc.
RCV-5000 IR to RS-232 Output Table
Device: RUNCO PL-50C3611 Projector

Infrared Remote Control: Philips PRONTO, Niles Intellicontrol
 Infrared Code Format: NEC - Device ID: 7B02
 Infrared Pronto Data File(s): See "IR Code Read Me - RCV-5000.txt" for complete description
 Infrared Receiver: Celadon RCV-5000 Infrared to RS-232 Receiver
 RCV-5000 Data File: runco3_r.hex
 Data: 9600 Baud, 8, N, 1, ASCII Output
 Standard Pinout
 Command Format: <input><aspect ratio>
 Dash (-) is used in place of input or aspect ratio for single commands
 Carriage Return at end of each command

Runco pl-50c3611 Command	Pronto Button	RCV-5000 Output
Power - ON	0	ON
Power - OFF	1	OF
Input - Composite	2	0-
Input - S-Video	3	1-
Input - Component	4	2-
Input - Pass Through	5	3-
Aspect - Anamorphic	6	-A
Aspect - LetterBox	7	-L
Aspect - Standard 4:3	8	-S
Aspect - YUV HDTV	9	-Y
Aspect - RGB HDTV	10	-R
Aspect - Computer (for pass through)	11	-C

Celadon, Inc.
 50 Mitchell Blvd.
 San Rafael, CA 94903
 Sales: (707) 648-1098
 Main Tel: (415) 472-1177
 Main Fax: (415) 472-1179
 sales@celadon.com